

SHARP

USER MANUAL EN

9.8" CIRCULATION FAN WITH REMOTE CONTROL

Model: PJ-CD114V-C

Important

Please read this user manual carefully before operating the product.
Please keep this user manual for reference.

Caution

- For safety, turn off the fan and unplug the fan's power cord from the AC outlet before cleaning or moving the fan.
- Only use the fan with a power source of the voltage indicated on the warning label. Before connecting the fan to a power source, ensure it is only connected to a matching power source.
- Do not stick your fingers or other objects into the fan.
- Do not attempt to repair the fan yourself. Always take the fan to an authorized warranty center for repairs.
- Do not immerse the fan in water or other liquids.
- Do not use it outdoors or near windows; rain may pose an electrical hazard.
- If the power cord is damaged, take it to an authorized warranty center to have it replaced to avoid danger.
- Do not use the following substances to clean the fan: Gasoline, thinner, or benzene.
- Use a mild - detergent soap, soak it into a damp cloth or sponge to wipe and clean plastic components.
- Only use it for household purposes; not for any commercial use.
- This device is not intended for people (including children) with physical or mental impairments, lack of experience and knowledge. Unless they are supervised or instructed on how to use it by a person responsible for their safety. Children need to be supervised to ensure they do not play with the device.
- Do not operate the Fan without the Fan Blade, or if the Fan Blade is damaged or bent.

Technical Specifications

Fan Size	Power Supply	Power	Wind speed	Fan Speed Gears
9.8"	24 V DC	36W	6.3 m/s	8

* Technical specifications may be changed without prior notice.

Label each component

- Front Net
- Aromatherapy Box
- Rear Net
- Control Panel
- Power Adapter Socket
- Vertical Pole 1
- Vertical Pole 2
- Chassis
- Digital screen
- Turbo Indicator Light
- Sleep Wind Indicator Light
- Baby Wind Indicator Light
- Smart Wind Indicator Light
- Ion Cluster Indicator Light
- Timer Indicator Light
- On/Standby Button
- Swing Button
- Speed Button
- Mode Button
- Turbo Button
- Ion Group Button
- Timer Button

Operation Instructions

- Insert the adapter into the 220 ~ 240V, 50Hz AC power socket, and plug one end into the fan's power port.
- Press the speed button to adjust the speed, with a total of 8speeds; Press the swing button to turn swing on/off; Press the mode button to adapt the wind mode: Normal Wind → Sleep Wind → Baby & Maternity Wind → Smart Wind. Press the storm button to turn storm mode on/off; Press the ion clusterbutton to turn ion cluster mode on/off; Press the timer button to adjust the timigduration.

Assembly method

- Installation of the Vertical Pole and Chassis
- Rotate the head and the chassis clockwise to connect the two vertical poles (as shown in the figure).
 - After connecting the bottom vertical pole to the chassis, rotate and tighten the nut to fix it.

Adding Aromatherapy

- Aromatherapy Box Aromatherapy Cotton Sheet
- Rotate the aromatherapy box counterclockwise to remove it from the machine.
 - Take out the aromatherapy cotton sheet, add essential oil, and put it back into the aromatherapy box.
 - Rotate the aromatherapy box clockwise to attach it to the machine.

Remote control instructions

Before using the remote control

- Insulating sheet
- Please pull out the insulating sheet before first use.

Battery Replacement Instructions

- Buckle position
 - Press and hold the buckle position to open the battery slot.
- Buckle position
 - Insert the battery (CR2025), and please ensure the "+" pole faces upward as shown in the diagram.
- Buckle position
 - Fit the battery slot back into the remote control.

CAUTION

- DO NOT recharge this battery;
- Keep out of children's reach;
- If ingested, seek immediate medical help;
- When operating fan, POINT remote at DISPLAY;
- Remote frequency may OVERLAP. Keep away from other electronics to prevent malfunction;
- Power buttons/remote DON'T fully cut power. Unplug during extended disuse;
- During prolonged storage, REMOVE batteries.

Button Functions

Standby Button	Controls the power - on and standby of the main unit.
Gear Button	Adjusts the wind speed gears, with a range of 1-8 gears.
Swing Button	Turn on or off the left - right swing function.
M Mode Button	Adjusts the mode function of the fan.
Turbo Button	Turns on or off the turbo mode
Ion Group Button	Turns on or off the ion group function.
Timer Button	Turns on or off the timer function, with a range of 1 - 6h.

Operation Modes of Functions

Power on	When powered on for the first time, the buzzer will emit a "beep" sound, all indicator lights will turn on for 1 second and then go off, and the device will enter the standby state.
On / Standby	In the standby state, press the "Standby" button on the remote control or the body, the buzzer beeps once, the fan starts to run, and the gear is 1st gear. The indicator light above the corresponding gear lights up. In the power - on state, press the "Standby" button on the remote control or the body, the buzzer beeps for a long time "beep--", and the fan enters the standby state.
Gear Adjustment	When the fan is in the running state, press the "Gear" button on the remote control or the fuselage. The buzzer will beep once, and the gear will be cycled and switched in the following way. The corresponding indicator light will turn on. When adjusting from gear 8 to gear 1, the buzzer will beep twice. 1→2→3→...→8→1→2...
Swing Function	When the fan is running, press the "Swing" button on the fan body or the remote control. The buzzer will beep once, and the left - right swing function will be turned on. Press the button again, the buzzer will beep twice, and the left - right swing function will be turned off. Automatic left-right oscillation (approx. 90°), manual up-down oscillation (90°).
Mode Switching	When the fan is powered on, it defaults to the normal wind mode, and the speed level is displayed. When the fan is running, press the "M" button on the body or the remote control, and the buzzer will emit a "beep". The modes will be cycled and switched in the following order: When switching from smart wind mode to normal wind mode, the buzzer will emit two "beeps". Normal wind → Sleep wind → Baby wind → AI Smart wind
Timer Function	When the fan is running, press the "Timer" button on the remote control, the buzzer beeps once, and the timer is cyclically selected as follows. The indicator light above the corresponding icon lights up. 1h→2h→3h→...→8h→Off(Cancel)→1h...
Storm Mode	When the fan is running, press the "Storm" button on the remote control. The buzzer will beep once, and the storm mode will be activated, with the corresponding indicator light turning on. Press the "Storm" button again to exit the storm mode, and the buzzer will beep twice as a prompt.
Ion Group	When the fan is running, press the "Ion" button on the remote control briefly, and the buzzer will beep once "beep". The ion group function will be turned on, and the "+" indicator light will light up. Press the "Ion" button on the remote control briefly again, and the buzzer will beep twice "beep beep". The ion group function will be turned off, and the "+" indicator light will go out.

SHARP

HƯỚNG DẪN SỬ DỤNG VI

9.8" QUẠT TUẦN HOÀN SHARP CÓ ĐIỀU KHIỂN

Kiểu Máy: PJ-CD114V-C

Quan trọng

Xin hãy đọc sách hướng dẫn sử dụng này cẩn thận trước khi thao tác sản phẩm.
Hãy cất giữ sách hướng dẫn sử dụng này để tham khảo về

Chú ý

- Đảm bảo an toàn, hãy tắt quạt và tháo dây điện nguồn quạt ra khỏi ổ điện AC trước khi vệ sinh hay di chuyển quạt.
- Chỉ sử dụng quạt với nguồn điện cùng điện áp được dán trên nhãn cảnh báo. Trước khi kết nối quạt với nguồn điện, đảm bảo rằng chỉ kết nối với nguồn điện tương ứng.
- Không chèn ngón tay hoặc vật khác vào quạt.
- Không được tự ý sửa chữa quạt. Luôn mang quạt đến trung tâm bảo hành ủy quyền để được sửa chữa.
- Không ngâm quạt trong nước hoặc các chất lỏng khác.
- Không sử dụng ngoài trời hoặc gần cửa sổ, mưa rơi có thể gây nguy hiểm về điện.
- Nếu dây điện nguồn bị hư, phải mang đến trung tâm bảo hành ủy quyền để được thay thế dây mới để tránh nguy hiểm.
- Không sử dụng các chất sau để vệ sinh quạt : Xăng dầu , thinner hoặc benzene.
- Sử dụng xà phòng có chất tẩy nhệ thấm vào vải ướt hoặc miếng xốp lau chùi để vệ sinh các bộ phận bằng nhựa.
- Chỉ sử dụng cho hộ gia đình, không dành cho bất kỳ mục đích kinh doanh.
- Thiết bị này không dành cho những người (kể cả trẻ em) có sức khỏe yếu, vấn đề thần kinh, thiếu kinh nghiệm và kiến thức. Từ khi họ có người giám sát hoặc hướng dẫn cách sử dụng bởi những người chịu trách nhiệm về sự an toàn của họ. Trẻ em cần được giám sát để đảm bảo rằng chúng không chơi với thiết bị.
- Không vận hành Quạt mà không có Cánh Quạt, Cánh Quạt bị hỏng hoặc cong.

Thông số kỹ thuật

Kích thước quạt	Nguồn điện	Công suất	Tốc độ gió	Tốc độ quạt
9.8"	24 V DC	36W	6.3 m/s	8

* Thông số kỹ thuật có thể được thay đổi mà không thông báo trước.

Chú thích các bộ phận

- Lưới Trước
- Hộp Thơm
- Lưới Sau
- Bảng Điều Khiển
- Jack Ngủ Mềm Rộng
- Cột Độc 1
- Cột Độc 2
- Chân đế
- Màn Hình Số
- Đèn Chỉ Thị Turbo
- Đèn Chỉ Thị Gió Ngủ
- Đèn Chỉ Thị Gió Trẻ Em
- Đèn Chỉ Thị Gió Thông Minh
- Đèn Chỉ Thị Tụ Ion
- Đèn Chỉ Thị Hẹn Giờ
- Nút Bật/Chở
- Nút Đảo Trái/Phải
- Nút Tốc Độ
- Nút Chế Độ
- Nút Turbo
- Nút Ion
- Nút Hẹn Giờ

Hướng dẫn thao tác

- Đảm đầu nối tiếp vào ổ cắm điện AC 220 - 240V, tần số 50Hz và cắm một đầu vào cổng nguồn của quạt.
- Nhấn nút tốc độ để điều chỉnh tốc độ, có tổng cộng 8 cấp tốc độ Nhấn nút đảo để bật/tắt chức năng đảo; Nhấn nút chế độ để điều chỉnh chế độ gió; Gió Thường → Gió Ngủ → Gió Trẻ Em & Mẹ Bầu → Gió Thông Minh; Nhấn nút turbo để bật/tắt chế độ turbo; Nhấn nút ion để bật/tắt chế độ tụ ion; Nhấn nút hẹn giờ để điều chỉnh thời gian hẹn giờ.

Cách lắp ráp

- Cài đặt Cột Độc và Khung Chassis
- Xoay đầu và khung chassis theo hướng kim đồng hồ để kết nối hai cột độc (như hình minh họa).
 - Sau khi kết nối cột độc dưới cùng với khung chassis, xoay và chặt các vít để cố định nó.

Thêm Thơm Môi Trường

- Hộp Thơm Tấm Cotton Thơm
- Xoay hộp thơm theo hướng ngược kim đồng hồ để tháo nó ra khỏi máy.
 - Lấy tấm cotton thơm ra, thêm dầu tinh khiết, sau đó đặt lại vào hộp thơm.
 - Xoay hộp thơm theo hướng kim đồng hồ để gắn nó vào máy.

Hướng dẫn sử dụng điều khiển từ xa

Trước khi sử dụng điều khiển từ xa

- Tấm cách điện
- Vui lòng kéo ra tấm cách điện trước khi sử dụng lần đầu.

Hướng dẫn thay pin

- Vị trí móc khóa
 - Nhấn và giữ vị trí móc khóa để mở khe cắm pin.
- Vị trí móc khóa
 - Đặt pin (CR2025) và vui lòng đảm bảo cực "+" hướng lên như trong sơ đồ.
- Vị trí móc khóa
 - Đặt lại khe cắm pin vào điều khiển từ xa.

CẢNH BÁO

- KHÔNG sạc lại pin này;
- Đề xa tầm tay trẻ em;
- Nếu nuốt phải, cần tìm kiếm sự trợ giúp y tế ngay lập tức;
- Khi vận hành quạt, hãy HƯỚNG điều khiển về phía MÀN HÌNH HIỂN THỊ;
- Tần số điều khiển từ xa có thể BỊ TRUNG. Để xa các thiết bị điện tử khác để tránh sự cố;
- Các nút nguồn/điều khiển từ xa KHÔNG ngắt hoàn toàn nguồn điện. Hãy rút phích cắm khi không sử dụng trong thời gian dài;
- Khi cất giữ lâu dài, THAO pin ra.

Chức năng của các nút

Nút Chở	Kiểm soát nguồn - bật và đặt máy chính ở chế độ chờ.
Nút Cấp Tốc Độ	Điều chỉnh các cấp tốc độ gió, với phạm vi từ 1 đến 8 cấp.
Nút Lắc Động	Bật hoặc tắt chức năng lắc trái - phải.
Nút Chế Độ	Điều chỉnh chức năng chế độ của quạt.
Nút Turbo	Bật hoặc tắt chế độ turbo.
Nút Tụ Ion	Bật hoặc tắt chức năng tụ ion.
Nút Hẹn Giờ	Bật hoặc tắt chức năng hẹn giờ, với phạm vi 1 - 6 giờ.

Chế độ hoạt động của các chức năng

Bật Nguồn	Khi bật nguồn lần đầu, buzzer sẽ phát âm thanh "beep", tất cả đèn báo sẽ sáng trong 1 giây rồi tắt, và thiết bị sẽ vào trạng thái chờ.
Bật / Chở	Trong trạng thái chờ, nhấn nút "Standby" trên điều khiển từ xa hoặc thân máy, buzzer kêu 1 lần, quạt bắt đầu quay, và cấp tốc độ là cấp 1. Đèn báo phía trên cấp tương ứng sẽ sáng. Trong trạng thái bật nguồn, nhấn lâu nút "Standby" trên điều khiển từ xa hoặc thân máy, buzzer kêu liên tục "beep--", và quạt vào trạng thái chờ.
Điều chỉnh Cấp Tốc Độ	Khi quạt đang quay, nhấn nút "Gear" trên điều khiển từ xa hoặc thân máy. Buzzer sẽ kêu 1 lần, và cấp tốc độ sẽ lập và chuyển đổi theo cách sau. Đèn báo tương ứng sẽ sáng. Khi điều chỉnh từ cấp 8 sang cấp 1, buzzer sẽ kêu 2 lần. Chuẩn chuyển đổi: 1→2→3→...→8→1→2...
Chức Năng Lắc Động	Khi quạt đang hoạt động, nhấn nút "Swing" trên thân quạt hoặc điều khiển từ xa. Máy báo sẽ kêu một lần và chức năng lắc trái - phải sẽ bật. Nhấn lại nút đó, máy báo sẽ kêu hai lần và chức năng lắc trái - phải sẽ tắt. Tự động xoay trái phải khoảng 90°, thủ động xoay lên xuống 90°.
Chuyển Chế Độ	Khi quạt bật nguồn, mặc định vào chế độ gió thông thường, và mức tốc độ sẽ hiển thị. Khi quạt đang quay, nhấn nút "M" trên thân máy hoặc điều khiển từ xa, và buzzer sẽ phát âm "beep". Các chế độ sẽ lập và chuyển đổi theo thứ tự sau. Khi chuyển từ chế độ gió thông minh sang chế độ gió thông thường, buzzer sẽ phát 2 tiếng "beep". Gió thông thường → Gió Ngủ → Gió Trẻ em → AI Gió thông minh
Chức Năng Hẹn Giờ	Khi quạt đang quay, nhấn nút "Timer" trên điều khiển từ xa, buzzer sẽ kêu 1 lần, và hẹn giờ sẽ được chọn lập như sau. Đèn báo phía trên biểu tượng tương ứng sẽ sáng. Chuẩn chọn giờ: 1h→2h→3h→...→8h→Off (Hủy)→1h...
Chế Độ Bảo	Khi quạt đang hoạt động, nhấn nút "Storm" trên điều khiển từ xa. Máy báo sẽ kêu một lần, và chế độ bảo sẽ được kích hoạt, với đèn báo tương ứng sáng lên. Nhấn lại nút "Storm" để thoát chế độ bảo, và máy báo sẽ kêu hai lần như một lời nhắc.
Tụ Ion	Khi quạt đang hoạt động, nhấn ngắn nút "Ion" trên điều khiển từ xa, và máy báo sẽ kêu một lần "beep". Chức năng tụ ion sẽ được bật, và đèn báo "+" sẽ sáng lên. Nhấn lại ngắn nút "+" trên điều khiển từ xa, và máy báo sẽ kêu hai lần "beep beep". Chức năng tụ ion sẽ được tắt, và đèn báo "+" sẽ tắt.

Size: 630*148mm

Printed on both sides, accordion fold

12 pages; 80g offset paper