

SHARP

USER MANUAL EN

7" CIRCULATION FAN WITH REMOTE CONTROL

Model: PJ-CD603V-C

Important

Please read this user manual carefully before operating the product.
Please keep this user manual for reference.

Caution

- For safety, turn off the fan and unplug the fan's power cord from the AC outlet before cleaning or moving the fan.
- Only use the fan with a power source of the voltage indicated on the warning label. Before connecting the fan to a power source, ensure it is only connected to a matching power source.
- Do not stick your fingers or other objects into the fan.
- Do not attempt to repair the fan yourself. Always take the fan to an authorized warranty center for repairs.
- Do not immerse the fan in water or other liquids.
- Do not use it outdoors or near windows; rain may pose an electrical hazard.
- If the power cord is damaged, take it to an authorized warranty center to have it replaced to avoid danger.
- Do not use the following substances to clean the fan: Gasoline, thinner, or benzene.
- Use a mild - detergent soap, soak it into a damp cloth or sponge to wipe and clean plastic components.
- Only use it for household purposes; not for any commercial use.
- This device is not intended for people (including children) with physical or mental impairments, lack of experience and knowledge. Unless they are supervised or instructed on how to use it by a person responsible for their safety. Children need to be supervised to ensure they do not play with the device.
- Do not operate the Fan without the Fan Blade, or if the Fan Blade is damaged or bent.

Technical Specifications

Fan Size	Power Supply	Power	Wind speed	Fan Speed Gears
7"	24 V DC	24W	5.3 m/s	3

* Technical specifications may be changed without prior notice.


Label each component

- Front Net
- Aromatherapy box
- Control Panel
- Rear Net
- Power Adapter Socket
- Vertical Pole 1
- Vertical Pole 2
- Chassis
- Normal mode indicator
- Sleep mode indicator
- Baby mode indicator
- Natural Wind Indicator
- Ion Group Indicator
- Speed level indicator
- Swing indicator
- Timer Indicator
- Swing Button
- Speed Gear Button
- On/Standby Button
- Timer Button
- Mode Button
- Ion Group Button

Operation Instructions


- Insert the adapter into the 220 - 240V, 50Hz AC power socket, and plug one end into the fan's power port.
- Press the gear button to adjust the gear level; Press the swing button to turn on/off the swing function; Press the timer button to adjust the timing duration; Press the mode button to select the wind type mode; Press the ion group button to turn on/off the ion group function.

Assembly method




Chassis Assembly

Connect the two straight rods, then insert them into the center hole of the chassis, and tighten and fix them by rotating the nut clockwise.



Main Unit Assembly

Insert the connecting socket at the fan head into the connecting socket slot of the straight rod, and tighten and fix it by rotating clockwise.




Assembly Heights

The product combination has three heights, and the upright column can be combined according to your usage needs.


Remote control instructions

Before using the remote control




- Please pull out the insulating sheet before first use.


Battery Replacement Instructions



- Press and hold the buckle position to open the battery slot.



- Insert the battery (CR2025), and please ensure the "+" pole faces upward as shown in the diagram.



- Fit the battery slot back into the remote control.

Please recycle used batteries.

CAUTION

- DO NOT recharge this battery;
- Keep out of children's reach;
- If ingested, seek immediate medical help;
- When operating fan, POINT remote at DISPLAY;
- Remote frequency may OVERLAP. Keep away from other electronics to prevent malfunction;
- Power buttons/remote DON'T fully cut power. Unplug during extended disuse;
- During prolonged storage, REMOVE batteries.

Button Functions

Standby Button	Controls the power - on and standby of the main unit.
Speed Button	Adjusts the wind speed gears, with a range of "Nhe-Vua-Manh" gears.
Swing Button	Turn on or off the left - right oscillation function.
Mode Button	Adjusts the mode function of the fan.
Ambient Light Button	Turns on or off the ambient light function.
Ion Group Button	Turns on or off the ion group function.
Timer Button	Turns on or off the timer function, with a range of 1 - 7h.

Operation Modes of Functions

Power on	When powered on for the first time, the buzzer will emit a "beep" sound, all indicator lights will turn on for 1 second and then go off, and the device will enter the standby state.
On / Standby	In the standby state, press the "On" button on the remote control or the body, the buzzer beeps once, the fan starts to run, and the gear is 1st gear. The indicator light above the corresponding gear lights up. In the power - on state, press the "On" button on the remote control or the body, the buzzer beeps for a long time "beep-", and the fan enters the standby state.
Gear Adjustment	When the fan is in the running state, press the "Gear" button on the remote control or the fuselage. The buzzer will beep once, and the gear will be cycled and switched in the following way. The corresponding indicator light will turn on. When adjusting from gear "Manh" to gear "Nhe", the buzzer will beep twice. Nhe ->Vua ->Manh ->Nhe.
Swing Function	When the fan is running, press the "Swing" button on the fan body or remote control. The buzzer will beep once, the left-right swing function will turn on, and the "Swing" indicator light will illuminate. Press the button again, the buzzer will beep twice, the left-right swing function will turn off, and the "Swing" indicator light will go out. Automatic left-right oscillation (approx. 55'), manual up-down oscillation (90').
Mode Switching	The fan defaults to the normal wind mode when powered on, and the "Mode" indicator light lights up. When the fan is running, press the "M" button on the body or the remote control, the buzzer beeps once, and the modes are cycled and switched as follows. When switching from natural wind to normal wind, the buzzer beeps twice "beep beep". Normal wind -> Sleep wind -> Baby wind -> Natural wind
Timer Function	When the fan is running, press the "Timer" button on the remote control, the buzzer beeps once, and the timer is cyclically selected as follows. The indicator light above the corresponding icon lights up. 1h ->2h ->3h... ->7h. Cancel the timer ->1h....
Ion Group	When the fan is running, press the "Ion" key on the remote control briefly, and the buzzer will beep once "beep". The ion group function will be turned on, and the "Ion" indicator light will light up. Press the "Ion" button on the remote control briefly again, and the buzzer will beep twice "beep beep". The ion group function will be turned off, and the "Ion" indicator light will go out.

SHARP

HƯỚNG DẪN SỬ DỤNG VI

7" QUẠT TUẦN HOÀN SHARP CÓ ĐIỀU KHIỂN

Kiểu Máy: PJ-CD603V-C

Quan trọng

Xin hãy đọc sách hướng dẫn sử dụng này cẩn thận trước khi thao tác sản phẩm.
Hãy cất giữ sách hướng dẫn sử dụng này để tham khảo về

Chú ý

- Đảm bảo an toàn, hãy tắt quạt và tháo dây điện nguồn quạt ra khỏi ổ điện AC trước khi vệ sinh hay di chuyển quạt.
- Chỉ sử dụng quạt với nguồn điện cung điện áp được dán trên nhãn cảnh báo. Trước khi kết nối quạt với nguồn điện, đảm bảo rằng chỉ kết nối với nguồn điện tương ứng.
- Không chèn ngón tay hoặc vật khác vào quạt.
- Không được tự ý sửa chữa quạt. Luôn mang quạt đến trung tâm bảo hành ủy quyền để được sửa chữa.
- Không ngâm quạt trong nước hoặc các chất lỏng khác.
- Không sử dụng ngoài trời hoặc gần cửa sổ, mưa rơi có thể gây nguy hiểm về điện.
- Nếu dây điện nguồn bị hư, phải mang đến trung tâm bảo hành ủy quyền để được thay thế dây mới để tránh nguy hiểm.
- Không sử dụng các chất tẩy rửa để vệ sinh quạt: Xăng dầu, thinner hoặc benzene.
- Sử dụng xà phòng có chất tẩy nhẹ thấm vào vải ướt hoặc miếng xốp lau chùi để vệ sinh các bộ phận bằng nhựa.
- Chỉ sử dụng cho hộ gia đình, không dành cho bất kỳ mục đích kinh doanh.
- Thiết bị này không dành cho những người (kể cả trẻ em) có sức khỏe yếu, vấn đề thần kinh, thiếu kinh nghiệm và kiến thức. Trừ khi họ có người giám sát hoặc hướng dẫn cách sử dụng bởi những người chịu trách nhiệm về sự an toàn của họ. Trẻ em cần được giám sát để đảm bảo rằng chúng không chơi với thiết bị.
- Không vận hành Quạt mà không có Cánh Quạt, Cánh Quạt bị hỏng hoặc cong.

Thông số kỹ thuật

Kích thước quạt	Nguồn điện	Công suất	Tốc độ gió	Tốc độ quạt
7"	24 V DC	24W	5.3 m/s	3

* Thông số kỹ thuật có thể được thay đổi mà không thông báo trước.


Chú thích các bộ phận

- Lưới trước
- Hộp thơm
- Bán điều khiển
- Lưới sau
- Cổng nguồn
- Cột dọc 1
- Cột dọc 2
- Chân đế
- Mục hiện chế độ thông thường
- Mục hiện chế độ ngủ
- Mục hiện chế độ trẻ em
- Mục hiện Gió Tự nhiên
- Mục hiện Tập hợp Ion
- Mục hiện mức tốc độ
- Mục hiện quay ngang
- Mục hiện hẹn giờ
- Nút quay ngang
- Nút mức tốc độ
- Nút bật/Tắt
- Nút hẹn giờ
- Nút chế độ
- Nút Ion

Hướng dẫn thao tác


- Cắm đầu nối ắc quy vào lỗ cắm điện xoay chiều 220 - 240V, tần số 50Hz và cắm đầu kia vào cổng nguồn của quạt.
- Nhấn nút mức tốc độ để điều chỉnh mức tốc độ; Nhấn nút quay ngang để bật/tắt chức năng quay ngang; Nhấn nút hẹn giờ để điều chỉnh thời gian hẹn giờ; Nhấn nút chế độ để chọn chế độ gió; Nhấn nút ion để bật/tắt chức năng ion.

Cách lắp ráp




Lắp ráp khung cơ sở

Kết nối hai thanh thẳng, sau đó đưa chúng vào lỗ chính của khung cơ sở và quay nút kim đồng hồ để thật chặt và cố định chúng.



Lắp ráp cơ sở chính

Đưa ổ cắm nối ở đầu quạt vào khe ổ cắm nối của thanh thẳng và quay kim đồng hồ để thật chặt và cố định nó.




Chiều cao lắp ráp

Sản phẩm có ba chiều cao và cột thẳng đứng có thể được kết hợp theo nhu cầu sử dụng của bạn.

Hướng dẫn sử dụng điều khiển từ xa


Trước khi sử dụng điều khiển từ xa




- Vui lòng kéo ra tấm cách điện trước khi sử dụng lần đầu.



- Nhấn và giữ vị trí móc khóa để mở khe cắm pin.



- Đặt pin (CR2025) và vui lòng đảm bảo cực "+" hướng lên như trong sơ đồ.



- Đặt lại khe cắm pin vào điều khiển từ xa.

Vui lòng tái chế pin đã sử dụng.

CẢNH BÁO

- KHÔNG sạc lại pin này;
- Để xa tầm tay trẻ em;
- Nếu nuốt phải, cần tìm kiếm sự trợ giúp y tế ngay lập tức;
- Khi vận hành quạt, hãy HƯỚNG điều khiển về phía MÀN HÌNH HIỂN THỊ;
- Tần số điều khiển từ xa có thể BỊ TRÙNG. Để xa các thiết bị điện tử khác để tránh sự cố;
- Các nút nguồn/điều khiển từ xa KHÔNG ngắt hoàn toàn nguồn điện. Hãy rút phích cắm khi không sử dụng trong thời gian dài;
- Khi cất giữ lâu dài, THAO pin ra.

Chức năng của các nút

Nút Chờ Sẵn	Kiểm soát việc bật nguồn và trạng thái chờ sẵn của đơn vị chính.
Nút Cấp Tốc Độ	Điều chỉnh cấp tốc độ gió, với phạm vi từ "Nhe-Vua-Manh" cấp.
Nút Động Cơ Dao Động	Bật hoặc tắt chức năng dao động trái - phải.
Nút Cấp Độ	Điều chỉnh chức năng chế độ của quạt.
Nút đèn xung quanh	Bật hoặc tắt chức năng ánh sáng xung quanh.
Nút Nhóm Ion	Bật hoặc tắt chức năng nhóm ion.
Nút Hẹn Giờ	Bật hoặc tắt chức năng hẹn giờ, với phạm vi từ 1 đến 7 giờ.

Chế độ hoạt động của các chức năng

Bật nguồn	Khi bật nguồn lần đầu tiên, buzzer sẽ phát ra âm thanh "beep", tất cả các đèn báo sẽ bật trong 1 giây sau đó tắt, và thiết bị sẽ vào trạng thái chờ sẵn.
Bật / Chờ sẵn	Trong trạng thái chờ sẵn, nhấn nút "On" trên điều khiển từ xa hoặc trên thân thiết bị, buzzer kêu một lần, quạt bắt đầu quay và tốc độ là cấp 1. Đèn báo phía trên cấp tốc độ tương ứng sẽ bật lên. Trong trạng thái bật nguồn, nhấn và giữ nút "On" trên điều khiển từ xa hoặc trên thân thiết bị, buzzer kêu một tiếng dài "beep-", và quạt vào trạng thái chờ sẵn.
Điều chỉnh cấp tốc độ	Khi quạt đang ở trạng thái hoạt động, nhấn nút "Speed" trên điều khiển từ xa hoặc trên thân thiết bị. Buzzer sẽ kêu một lần, và cấp tốc độ sẽ được vòng lặp và chuyển đổi theo cách sau. Đèn báo tương ứng sẽ bật lên. Khi điều chỉnh từ cấp Mạnh sang cấp Nhe, buzzer sẽ kêu hai lần. Nhe ->Vua ->Manh ->Nhe....
Chức năng dao động	Khi quạt đang hoạt động, nhấn nút "Swing" trên thân quạt hoặc điều khiển từ xa. Loa còi sẽ phát ra một tiếng "beep", chức năng dao động trái-phải sẽ bật lên, và đèn báo "Swing" sẽ sáng lên. Khi quạt đang hoạt động, nhấn phím "M" trên thân quạt hoặc điều khiển từ xa, loa còi sẽ phát ra một tiếng "beep", và các chế độ sẽ được chuyển đổi tuần hoàn như sau. Khi chuyển từ gió tự nhiên sang gió bình thường, loa còi sẽ phát ra hai tiếng "beep beep".
Chuyển chế độ	Gió bình thường -> Gió ngủ -> Gió trẻ em -> Gió tự nhiên
Chức năng hẹn giờ	Khi quạt đang hoạt động, nhấn phím "Timer" trên điều khiển từ xa, loa còi sẽ phát ra một tiếng "beep", và hẹn giờ sẽ được chọn tuần hoàn như sau. Đèn báo phía trên biểu tượng tương ứng sẽ sáng lên. 1h ->2h ->3h... ->7h ->1h....
Nhóm ion	Khi quạt đang hoạt động, nhấn phím "Ion" trên điều khiển từ xa, loa còi sẽ phát ra một tiếng "beep". Chức năng nhóm ion sẽ được bật lên, và đèn báo "Ion" sẽ sáng lên. Nhấn phím "Ion" trên điều khiển từ xa lần nữa, loa còi sẽ phát ra hai tiếng "beep beep". Chức năng nhóm ion sẽ được tắt đi, và đèn báo "Ion" sẽ tắt đi.